INSTRUCTION MANUAL
ENGLISH

Max. 50 KG

KT-005-00-00 I KT-005-00-12

Never leave your child unattended!

READ THIS INSTRUCTION CAREFULLY!

Despite careful editing it is not possible to completely rule out printing errors or changes to product specifications at short notice. The pictures in this manual are indicative in nature and may vary from the actual product. In any case refer to the actual product. The kettcar and its components may be subject to product improvements. Thus, there can be changes in design, manufacturing, or construction without prior notification once all regulations and tests have been fully passed. For further information, please contact the KETTLER support team using the following email address: info@kettlershop.com.

INTRODUCTION

Please read these instructions carefully prior to carrying out assembly and using for the first time. They contain information, which is important for your safety as well as for the use and maintenance of the appliance. Keep these instructions in a safe place for reference purposes, maintenance work and ordering spare parts.

This KETTLER product has been designed in accordance with the latest standards of safety and subjected to constant quality monitoring. The data gained from this quality process is then incorporated in the development of our products. For this reason, we reserve the right to make changes in design and technology in order to offer our customers products of the highest standard of quality at all times. In spite of this, should you have any ground for complaint, please contact our KETTLER service directly.

SAFETY INSTRUCTIONS

WARNING! Use under adult supervision only!

WARNING! One person at a time only!

WARNING! Maximum weight is 50 kg.

WARNING! The vehicle must be only be used in a danger-free environment. Do not use the vehicle near hillsides, steps, streets, railway systems, stretches of water, etc. (danger of accidents, toppling over, falling, injuries); choose safe areas such as secure, even surfaces.

WARNING! Danger of accidents and severe injuries when used on public streets. Sturdy shoes must be worn during use. We recommend wearing suitable protective clothing and a safety helmet.

WARNING! Keep this toy away from children under the age of three!

WARNING! Not suitable for children under 3 years due to lack of motoric skills.

WARNING! Store the unused decorative stickers carefully and keep them away from small children. Contains small parts, choking hazard!

WARNING! Adult assembly only! Keep children away during assembly.

WARNING! Do not allow children to play with the packaging.

WARNING! As the product is only a toy it should not be used on public roads, because it does not conform to the road traffic regulations.

WARNING! The user must always adapt his/her way of driving to local conditions as well as his/her personal ability. There is danger of falling over at exaggerated bends at high speed and when turning the steering wheel.

WARNING! The toy must only be used by children who have sufficient motor abilities for safe use of the toy.

WARNING! This toy is designed only for private use (no commercial or public use).

WARNING! This vehicle is only to be used for its intended purposes, which is as a toy for the use of one (1) person. Any other use is not permitted and is possibly dangerous (injuries, accidents, falling over). The manufacturer cannot be held responsible for damages, which were caused by unintended use.

WARNING! This product is suitable for children from 5 years onward.

WARNING! This child's wheeled toy conforms to the safety regulations European standard EN 71-1/-2/-3 („Safety regulations for childrens toys"; max. weight of user: 50 kg). Incorrect repairs or alterations (removal of original parts or addition of other parts etc.) may be a source of danger to the user.

WARNING! Damaged parts may endanger the user and shorten the life span of the product. Please check all parts regularly, in short intervals according to use, for possible damages and loose connections (screws, plug-in connections).

WARNING! Damaged or worn parts must be replaced straight away and the vehicle must be withdrawn from use until repaired. If required only use original KETTLER spare parts.

WARNING! Improper repairs and structural alterations (disassembly of original parts, fitting of not permitted parts, etc.) may cause danger for the user or affect the life span of the product.

WARNING! As the product is only a toy it should not be used on public roads, it does not conform to the road traffic regulations.

WARNING! Please bear in mind that there is always a danger of children injuring themselves (falling off, tipping over etc.) whilst using swings, climbing frames, tricycles or similar equipment.

WARNING! Do not connect this toy to any other product; because this child's wheeled toy has not been designed for higher speeds.

WARNING! Please bear in mind that children are very often not able to judge their own capabilities and certain (dangerous) situations. Also consider that a natural urge to play plus their temperament may lead children into unforeseen situations for which the manufacturer cannot be held responsible.

WARNING! This wheeled toy does not have lights. It is dangerous to use it in the dark

HANDLING

- Before use always, check that all screws, plug-in connections and respective safety devices are correctly installed.
- Instruct children in the correct use of the product, and draw their attention to possible dangers.
- Please note that pedals on any wheeled toy without freewheeling appliance will turn even if the product is being pushed or is coasting.
- This wheeled toy does not have a so-called parking brake. Therefore secure the vehicle against rolling away. Do not leave children, who are not old enough to use the wheeled toy, unattended on a product.
- If this product can be adjusted please adapt it to your child's height.
- Do not transport anything on this product.
- Never use corrosive or abrasive substances to clean the toy. Never use substances which may cause pollution of the environment. Lubricate the bearing sleeves of the wheels and the handlebars with a few drops of oil every two or three months.

ASSEMBLY INSTRUCTIONS

WARNING! Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around. Always dispose packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!

- Please ensure that the vehicle will only be used for playing when assembly has been carried out correctly, and checked, by an adult.
- The toy vehicle must be assembled carefully by an adult person. Study the assembly instructions carefully. Assemble the vehicle in the exact sequence shown by the letters in the diagrams. This is essential for the safe function and use of the toy vehicle.
- Please note that there is always a danger of injury when working with tools or doing manual work. Therefore please be careful when assembling this machine.

- Bolt all the parts loosely together at first, and check that they have been assembled correctly. Tighten the lock nuts by hand until resistance is felt, then use a spanner to finally tighten nuts completely against resistance (locking device). Then check that all screw connections have been tightened firmly. **ATTENTION:** once locknuts have been unscrewed they no longer function correctly (the locking device is destroyed) and must be replaced.
- For technical reasons, we reserve the right to carry out preliminary assembly work (e.g. addition of tubing plugs).

PARTS LIST



ASSEMBLY

















MAINTENANCE AND SERVICE

- Damaged components may endanger your safety or reduce the lifetime of the equipment. For this reason, worn or damaged parts should be replaced immediately and the equipment taken out of use until this has been done. Use only original KETTLER spare parts.
- To ensure that the safety level is kept to the highest possible standard, determined by its construction, this product should be serviced regulary (once a year) by specialist retailers.